Notes:

1) Material: 1/2" thick plywood.
2) Apply a 2" wide, 45" long strip of adhesive backed hook Velcro on the bottom of the leading edge, as indicated. Use staples as well as the adhesive to attach.

DRAWN dfoster	9/1/2009	
CHECKED mcyr	12/2/2009	
UNLESS OTHERWISE SPECIFIED ***TOLERANCES: (INCHES)***		
FRAC.	+/- 1/32	
.00	+/- .01	
.000	+/- .005	
ANGULAR	+/- .25 Deg.	

FIRST
200 Bedford Street, Manchester, NH 03101
(603) 666-3906 -- FAX (603) 666-3907

TITLE
Floor Protector, Bump

SIZE	DWG NO	REV
B	GE-10002	

SCALE | SHEET 1 OF 1