Notes:

1) Material: 1/2" Plywood
2) Apply a 2" wide, 25-1/4" long strip of adhesive backed hook Velcro on the bottom of leading and trailing edge, as indicated. Use staples as well as the adhesive to attach.

DRAWN dfoster	9/2/2009
CHECKED mcyr	12/2/2009
UNLESS OTHERWISE SPECIFIED *TOLERANCES: (INCHES)*	
FRAC.	+/- 1/32
.00	+/- .01
.000	+/- .005
ANGULAR	+/- .25 Deg.

FIRST
200 Bedford Street, Manchester, NH 03101
(603) 666-3906 -- FAX (603) 666-3907

TITLE
Floor Protector, Tunnel

SIZE	DWG NO	REV
B	GE-10003	

SCALE

SHEET 1 OF 1